

Loreto Mounting Instructions

It's important that before starting that you carefully read this instruction and the instructions supplied inside the appliance.

Note, the surfaces of your fireplace can be scratched or damaged if care is not taken during installation. A second pair of hands will be necessary to complete this installation safely and damage free.

Mounting the Fire:

Ensure that you keep all screws removed for future use and spares

1. Decide on the height that you want the fire to be mounted from the floor, remember you need a flat wall with a nearby power socket.
2. The height from the bottom of the fire to the bottom of the bracket is 47mm.
3. Added the two measurements together and you will have the height to mount the bracket.
4. ***Ensure you have suitable fixings for the wall structure. Depending on the wall type additional wall strengthening may be necessary (seek advice if you are unsure) It must be securely fixed to the wall.***
5. Screw one side of the bracket to the wall and ensure that it is level by pivoting the bracket and using a spirit level before screwing the other side.
6. Take the engine and lift onto the hooks of the bracket.
7. To secure the fire to the bracket, screw the fire and the bracket together from the underneath using the two tabs that sit underneath the fire.

Fitting the Surround:

1. Remove the white KD transit blocks before fitting lifting the surround.
2. Slide the surround over the aperture of the fire.
3. For the bottom of the surround. Underneath, secure the surround to the wall using the brackets provided. Do this for both sides of the bottom (LEFT and RIGHT).
4. Job done! Enjoy your new fireplace!