

To prevent damage in transit the top is transpotred seperate from the main surround. Lift the engine into the cut out before placing the sides and bolts Line up pre drilled holes and bolt into place with bolts. for extra stability, screw up into the top section.

## DO NOT LIFT FROM THE TOP. LIFT FROM BASE

## LUMINESS HANDLE

- ٠
- ٠
- Line up handle holes with holes in door. using screws provided screw into handle by hand check handle is straight before tightening with screwdriver. •





